



Cleaner & Degreaser

**Cleans Electrical Equipment
Removes Grease, Dirt and Oil from
Metal, Wood, Canvas and Fabric
Leaves No Residue
Non Flammable**



Net Contents: 1 gal. (3.78 l) • Part No. 06021

DANGER: VAPOR HARMFUL. Read warnings on back panel.

CRC Cleaner & Degreaser

CRC Marine Cleaner & Degreaser is non-flammable, non-staining, non-conductive, and non-corrosive. It swiftly and effectively degreases, removes oil, dirt, wax, moisture and other foreign matters that cause electrical failures. Leaves no residue. Easily dissolves and removes grease and other contaminants from tools, motors, gears and other metal parts. Even removes oil and grease from wood, canvas and fabric.

CLEANS AND DEGREASES:

ELECTRIC MOTORS • STARTERS • ELECTRIC PUMPS • SOLENOIDS • WELDER'S TOOLS
CABLES • ALTERNATORS • TOOLS
COMMUTATORS • COILS • DISTRIBUTORS
CAMs • GENERATORS • RELAYS • BATTERIES
REGULATORS • METAL PARTS

WARNING: Contains Tetrachloroethylene 127-18-4. Vapor may decompose to harmful corrosive gases when exposed to flame or other heat sources. This product contains chemicals known to the State of California to cause cancer, birth defects and other reproductive harm. Overexposure to vapors may cause eye and skin irritation, headaches, nausea, dizziness, irritation to upper respiratory tract and irregular heartbeats. Deliberate misuse by concentrating and inhaling the contents can be harmful or fatal. Use only in a well ventilated area. Avoid continuous breathing of vapor and spray mist. Avoid contact with skin and eyes. Vapors are heavier than air and will collect in low areas. If ventilation is not adequate, respiratory protection should be used.

DISPOSAL: All used and unused product should be disposed of in accordance with federal, state and local regulations. DO NOT dump in sewers, floor drains, on the ground or into any body of water.

FIRST AID: In case of eye or skin contact, flush with water for 15 minutes. If swallowed, DO NOT induce vomiting. If too much is breathed, remove to fresh air. For severe overexposure, call a physician immediately. For additional information, consult the Material Safety Data Sheet for this product.

DIRECTIONS: Read entire label before use. Follow all directions.

NOT FOR USE ON SENSITIVE ELECTRONIC EQUIPMENT SUCH AS TAPE DECKS, VCRs, COMPUTERS, ETC. USE CRC PLASTIC SAFE CLEANER FOR THESE APPLICATIONS.

- DO NOT use on polycarbonate plastics such as LEXAN®. If in doubt, call the manufacturer of the equipment. MAY ALSO BE HARMFUL TO OTHER PLASTICS.
- Protect all rubber parts, plastic parts and painted surfaces from overspray. DO NOT apply directly on painted surfaces.
- Remove access plates to expose equipment interior. For hard to reach areas, use extension tube.
- Apply until clean by brushing, dipping or spraying.
- Air dry or dry with a soft cloth.
- Heavy deposits may require scraping and repeat applications.
- Do not apply while equipment is energized.

HANDLING & SPILL PRECAUTIONS: Keep container closed. Wash thoroughly after handling. Do not enter where vapors are suspected in high concentrations unless air supplied positive pressure breathing apparatus is used and a trained observer is present and equipped with rescue gear.

SPILLS: Use proper protective equipment. Take precautions to prevent contamination of ground and surface waters. For small spills, use absorbent and sweep into closed containers for disposal. For large spills, evacuate the area, dike and transfer into containers for disposal.

©1997 CRC Industries, Inc.
Warminster, PA 18974
800-521-3168 (Technical Information)
800-272-4620 (Customer Service)
Made in U.S.A. CRC491G 97A

