



## ***I. Product Description***

**CRC® Disinfecting Wipes** are proven to clean, disinfect and deodorize. CRC's EPA registered wipe formula can be used on most hard, non-porous surfaces to leave them clean and free from odors. Safe to use in schools, health clubs, gyms, athletic facilities, airports, transportation terminals, grocery stores, shopping centers, delicatessens, catering facilities and banquet halls.

## ***II. Applications***

### **DISINFECTS:**

Half mask respirators • goggles • face shields • gas masks • full face breathing apparatus • grocery carts & handles • shopping carts • cabinets • chairs • computers • countertops • desks • desktops • doorknobs • garbage cans • headsets • keyboards • railings • seats • sinks • tables • tabletops • telephones • trashcans • gym equipment • exercise machines • wrestling mats • gymnastic equipment

## ***III. Features & Benefits***

- Cleans, Disinfects & Deodorizes Hard Surfaces
- Virucidal – Tuberculocidal – Bactericidal – Pseudomonacidal
- Effective against MRSA and Norwalk Virus
- Bleach and Alcohol Free
- Fresh lemon scent

## ***IV. Physical Properties without propellant***

<b>Flash Point</b>	None	<b>Boiling Point</b>	212°F
<b>Odor</b>	Lemon - lime	<b>Freezing Point</b>	Not Determined
<b>Appearance</b>	Clear colorless (liquid)	<b>Solubility</b>	Soluble
<b>Vapor Density</b>	>1 (air =1)	<b>VOC Content (Fed)</b>	.13 g/L
<b>Vapor Pressure</b>	Not Determined	<b>VOC %</b>	.01%
<b>Prop 65</b>	Yes	<b>Specific Gravity</b>	1.009
		<b>pH</b>	11.7

## ***V. Specifications and Approvals***

EPA Reg. No. 1839-174-55809

## VI. Directions

**It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.**

This product is not to be used as a terminal sterilant/high level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body.

**CLEANING:** Use one CRC Disinfecting Wipe to completely remove all gross debris from surfaces to be treated.

**DISINFECTING:** To disinfect hard, non-porous surfaces, thoroughly wet the surface to be treated. Treated surface must remain visibly wet 10 minutes for disinfection against Escherichia coli (E. coli), Escherichia coli O157:H7, Pseudomonas aeruginosa, Salmonella choleraesuis, Vancomycin Resistant Enterococcus (VRE), Mycobacterium bovis BCG (Tuberculosis), Staphylococcus aureus, Methicillin Resistant Staphylococcus aureus (MRSA), and Vancomycin intermediate Resistant Staphylococcus aureus (VISA). A potable water rinse is required for surfaces in direct contact with food. For plastic and painted surfaces, spot test on an inconspicuous area before use. For heavily soiled surfaces, clean before following disinfecting instructions.

**\*VIRUCIDAL ACTIVITY:** CRC Disinfecting Wipes are an effective virucide on hard, non-porous surfaces against: Human Immunodeficiency Virus Type 1 (HIV-1) when the treated surface is allowed to remain wet for 2 minutes; and Norovirus (Norwalk Virus) and Feline calicivirus when the treated surface is allowed to remain wet for 10 minutes. Use additional wipes if needed to assure that the treated surface remains continuously wet for the prescribed time.

## VI. Package Description

Part Number	Container Size
04101	90 Wipe Container

## VII. Disposal

Disposal requirements vary by state and local jurisdiction. All used and unused product should be disposed of in conformance with local, state and federal regulations.

## VIII. Special Use Warnings

### General

Use only in well ventilated area. Ventilation may be improved by opening a window or door or providing mechanical assistance. Avoid contact with skin and eyes. For more information regarding short term and long term exposure, review this product's Material Safety Data Sheet.

**DISCLAIMER:** This information is accurate to the best of CRC Industries' knowledge or obtained from sources believed by CRC to be accurate. Before using any product, read all warnings and directions on the label. All products should be tested for suitability on a particular application prior to actual use. CRC Industries, Inc. makes no representations or warranties of any kind concerning this data.

CRC Industries, Inc.  
Technical Service: (800)521-3168

Industrial Products Division  
Customer Service: (800)272-4620

Warminster, PA 18974  
CRC On-Line: (215)442-6260