



SPIN DOCTOR™ PROPELLER GREASE with DuPont PTFE

A premium, synthetic, non-drying anti-seize compound engineered to provide a superior waterproof seal and protect against corrosion

Prevents prop shaft from seizing and proper torque is easier to achieve during assembly

Use on stainless steel, aluminum, brass, black iron, galvanized steel, copper, nibral & bronze

*Use one grease
packet per job
Contains
2 applications*



No. 06117 Net Wt. 14 g

SPIN DOCTOR™ PROPELLER GREASE with DuPont PTFE



Specially engineered for the harsh marine environment, SPIN DOCTOR Propeller Grease lubricates the propeller shaft and provides a superior waterproof seal to protect against corrosion. Won't melt or wash out! SPIN DOCTOR prevents the prop shaft from seizing and proper torque is easier to achieve during assembly. SPIN DOCTOR is biodegradable and does not contain any solvents, lead, graphite or clay fillers.

SPIN DOCTOR may be used on stainless steel, aluminum, brass, galvanized steel, black iron, copper, nibral and bronze, and is also suitable for folding propellers.

DIRECTIONS: Read entire label before use. Follow all directions.

Propeller shaft should be lubricated at least once each boating season, as well as during winter lay-up and when changing propellers. Regular lubrication is necessary to prevent the propeller from corroding to the propeller shaft. Refer to owner's manual for manufacturer's recommended service intervals.

1. Remove the propeller.
2. Remove any tangled fishing line or other debris.
3. Clean all parts – shaft, threads, washers, hub, prop nut – with CRC Marine Cleaner & Degreaser (06019).
4. Thoroughly coat propeller shaft with one 7 gram packet of SPIN DOCTOR Propeller Grease.
5. Reinstall the propeller.

CONTAINS: Magnesium Silicate 14807-96-6 and PTFE 9002-84-0.

FIRST AID: In case of eye contact, flush with water for at least 15 minutes.

For skin contact, wash with soap and water. See physician if irritation persists. If too much is inhaled, remove to fresh air. If swallowed, DO NOT induce vomiting. Call a physician.

IMPORTANT: Do not mix greases of different base type. Use a solvent to remove and clean out all traces of incompatible grease before repacking. Repack according to manufacturer's instructions.

KEEP OUT OF REACH OF CHILDREN

©2004 CRC Industries, Inc.
Warminster, PA 18974

800•521•3168 (Technical Information)
800•272•8963 (Customer Service)

No. 06117
Made in U.S.A. 04A
800•442•6260 (MSDS)
www.crcindustries.com

