



# Premium Grade SmartWasher® Filter

**Fluid Activation Filter for the SmartWasher® Parts Washing System**

- Contains 50% more microbes • Keeps cleaning solutions cleaner •

**TO INSTALL:** Remove the new mat from package and set aside. Turn off the SmartWasher® and remove the false bottom. Remove the used mat from SmartWasher® and wring out excess fluid. Insert used mat into empty poly bag for disposal. Install new filter **BLUE SIDE DOWN** (white side up) on top of mat support grid and replace the false bottom. Dispose of the used filter in accordance with local, state and federal regulations. **Refer to Operating Manual, if necessary, for further clarification.**

It is recommended that safety glasses and rubber gloves be worn when handling industrial-use products.

SmartWasher and ChemFree are registered trademarks of ChemFree Corporation.

Best if used by:



©2009 CRC Industries, Inc.  
Warminster, PA 18974  
www.crcindustries.com  
Made in U.S.A. 09A

800-521-3168 (Technical Information)  
800-272-4620 (Customer Service)  
215-442-6260 (MSDS)

**STORE IN A  
COOL, DRY  
PLACE. DO  
NOT WET  
UNTIL READY  
TO USE.**



Part No. 14147

Contents: 1 Filter